

ELECTRICAL GAUGES W/PEAK & WARNING

52mm CRYSTAL BLUE SERIES WHITE / AMBER LED DISPLAY

Air fuel / ratio

1

BACK VIEW

SET Button

Optional Warning Light Wire Harness

Power Wire Harness (Daisy Chain)

Sensor Wire Harness

Red Orange Black White

Power Wire Harness

- Red - Constant 12v (+)
- Black - Chassis Ground (-)
- White - Switched 12v (+)
- Orange - Headlight switch 12v (+)

2

The meter stand connection screw

Meter mount

Peak LED Blue

Warning LED Red

3

Warning Light Sold Separately

Double-Sided Tape

Harness

External Warning Light

Warning Light Wire Harness

4

Remove Key From Ignition

Remove Negative Battery Terminal

5

BACK VIEW

CONNECTOR FOR SENSOR WIRE

SENSOR WIRE

RED CONNECTOR

O2 SENSOR SIGNAL WIRE

WHITE

ECU (ENGINE COMPUTER UNIT)

6

Repalce negative terminal

Insert key to test

Boost / Vacuum Gauge

1

BACK VIEW

SET Button

Optional Warning Light Wire Harness

Power Wire Harness (Daisy Chain)

Sensor Wire Harness

Red Orange Black White

Power Wire Harness

- Red - Constant 12v (+)
- Black - Chassis Ground (-)
- White - Switched 12v (+)
- Orange - Headlight switch 12v (+)

2

The meter stand connection screw

Meter mount

Peak LED Blue

Warning LED Red

3

Warning Light Sold Separately

Double-Sided Tape

Harness

External Warning Light

Warning Light Wire Harness

4

Remove Key From Ignition

Remove Negative Battery Terminal

5

BOOST INSTALLATION

Sensor wiring harness

Pressure Regulator

Waterproof Boost / Vacuum Sensor

Surge Tank

T-Fitting

Air Filter

Hose

6

BACK VIEW

CONNECTOR FOR SENSOR WIRE

SENSOR WIRE

WHITE CONNECTOR

VACUUM / BOOST SENSOR

7

Repalce negative terminal

Insert key to test