


Premium Oil Pressure Gauge

Amber/White Display (270° Scale)



Setting warning / Mute Feature

To set the warning feature:

After the opening ceremony is complete, Press and hold the button down for approx 5 seconds until the pointer begins to blink. Release button. Push and hold button to move quickly across the scale or Toggle button to move pointer in small increments. Once you have the pointer where you want it, wait 5 seconds to "set" and pointer will stop blinking

Mute feature:


- 1.) With ignition key in off position, press and hold button- Turn Ignition on, wait for pointer to come to a rest then release button.
- 2.) To turn sound back on-Repeat step 1

Peak recall

- 1.) Push button one time to recall peak level. The Blue light will come on when gauge is in recall mode. The pointer will rise to the Highest level attained by the gauge and remain there approximately 5 seconds.
- 2.) To reset peak level: While in peak mode (blue light is on) press and hold button down




Color Diagram

Day Time	Night Time	Installation
White color	White color	White color — Connect to acc. Power Amber color — Do not connect
Amber color	Amber color	White color — Do not connect Amber color — Connect to acc. Power
White color	Amber color	White color — Connect to acc. Power Amber color — Connect to parking lamp
Amber color	White color	Amber color — Connect to acc. Power White color — Connect to parking lamp



Premium Oil/ Water Temperature Gauge

Amber/White Display (270° Scale)



Oil adapter plate sold Separate

